

FRONT OF FLYING PARTS

APPLY 3 COATS OF
SANDING SEALER
TO ALL PARTS

KEEP TIP THIN

3-1/2"

5/8"

DIHEDRAL DETAIL

NOTE WEDGE

1-1/2"

3"

TYPICAL AIRFOIL AT ROOT

TYPICAL AIRFOIL
AT TIP

SPLICE 2 SHEETS HERE

WING:

3/16" SHEET

TYPICAL STAB
AIRFOIL

STAB:

1/16" SHEET

AERO-WASP

DESIGNED TO STAY IN SIGHT
LONGER. HAS THIN WING FOR
FAST CLIMB. ADJUST TO MAKE
FULL CLIMB IN 1/2 CIRCLE TO
RIGHT. GLIDE LEFT.

ADD CLAY HERE TO BALANCE

WING POSITION 0°

FUSELAGE:

TYPICAL
SECTION

x